

Rumpstad

Lichaam	Rister	Inzetstuk	Zool, lang	Zool, kort	Schaarblad	Schaarpunt						
	Rechts Links	Rechts Links	Rechts Links	Rechts Links	Rechts Links	Rechts Links						
Stoppel	R.	RS 089	R.	RS 0928	R.	RS 0927	R.	RS 090				
Type 25	R. L.	RS 0116 RS0115	R. L.	RS 0544 RS 0545	R. L.	RS 032 RS 031	R. L.	RS 022 RS 021				
Type 30	R. L.	RS 0114 RS 0113	R. L.	RS 033 RS 034 met RS 0615 RS 0616	R. L.	RS 033 RS 034	R. L.	RS 0110 RS 0109				
Type 35												
Type 40	R. L.	RS 0212 RS 0213	R. L.	RS 5490 RS 5491	R. L.	RS 5488 RS 5489	R. L.	RS 1210 RS 1209				
TWL/DWL		R. L.	AR 019 AL 019	R. L.	RS 6492 RS 6491	R. L.	RS 6490 RS 6489	R. L.	AR 015 AL 015			
Type 212	R. L.	RS 0212 RS 0213	R. L.	RS 5490 RS 5491	R. L.	RS 5488 RS 5489	R. L.	RS 1210 RS 1209				
Type 312	R. L.	RS 0210 RS 0211	R. L.	RS 0312 RS 0311								
Type 280	R. L.	RS 28004 RS 28003	R. L.	RS 28006 RS 28005	R. L.	tot '90 RS 5490 RS 5491 vanaf '90 RS 11472 RS 11473 met RS 11478 RS 11479 Slijtstuk R./L. RS 11465	R. L.	tot '90 RS 5488 RS 5489 vanaf '90 RS 11472 RS 11473 met RS 11474 RS 11475	R. L.	RS 18104 RS 18103	R. L.	RS 18102 RS 18101 Omkeerbaar tot '99 RS 18136 RS 18135 met RS 18134 RS 18133 vanaf '99 RS 18136 RS 18135
Type 380	R. L.		R. L.	RS 28008 RS 28007	R. L.	RS 11472 RS 11473 met RS 11478 RS 11479 Slijtstuk R./L. RS 11465	R. L.	RS 18122 RS 18121	R. L.	Werkbr. 45 cm RS 18106 RS 18105	R. L.	
Type 480	R. L.	N.M.L. vanaf '01 RS 18486 RS 18487	R. L.	RS 18482 RS 18483	R. L.	RS 11472 RS 11473 met RS 11478 RS 11479 Slijtstuk R./L. RS 11465	R. L.	RS 11472 RS 11473 met RS 11474 RS 11475	R. L.		R. L.	
Type 580 Eco	R. L.	RS 20580 RS 20581	R. L.	RS 5488 RS 5489	R. L.	RS 20544 RS 20545	R. L.	RS 20582 RS 20583	R. L.	RS 20556 RS 20557		